



'OO' SUPER VOYAGER POWER UNIT

BODYSHELL TYPES:
 (REFER TO DATE PANELS
 ON ENDS OF CARS OR
 CONSIST DIAGRAM)

625-100 DMSL (T1)
 625-101 MS(A) (T2)
 625-102 MS(B) (T3A)
 625-103 MS(B) (T3B)
 625-104 DMF (T4)

IMPORTANT!

WHEN ORDERING ANY REPLACEMENT PARTS PLEASE ENSURE TO QUOTE THE APPROPRIATE CATALOGUE NUMBER/LIVERY OF YOUR BACHMANN LOCOMOTIVE, IN ADDITION TO THE NUMBER OF THE PART REQUIRED.

PLEASE NOTE WE WOULD LIKE TO BRING YOUR ATTENTION TO RUNNING-IN WHICH IS NECESSARY WITH THIS TYPE OF DRIVE.

RUN FOR APPROXIMATELY ONE HOUR TO ALLOW WORKING PARTS TO BED-IN. LIGHTLY OIL THEMOTOR BEARINGS AND GEARS WHEN REQUIRED.

